

MOBILE SENSING LEARNING



CS5323 & 7323

Mobile Sensing and Learning


doppler and activity monitoring

Eric C. Larson, Lyle School of Engineering,
Computer Science, Southern Methodist University

agenda and logistics

- logistics:
 - grades update
 - A2 is due soon!
- agenda:
 - A2 explanations
 - general FFT review
 - peak finding
 - the doppler effect
 - activity processing

class overview



A2 specifications


On Canvas

FFT review

- sampling rate
 - dictates the time between each sample, $(1 / F_s)$
 - max frequency we can measure is half of sampling rate
- resolution in frequency
 - tradeoff between length of FFT and sampling rate
 - each frequency “bin” is an index in the FFT array
 - each bin represents (F_s / N) Hz
 - what does that mean for 6 Hz accuracy?


time and frequency

Note: the FFT class **ALWAYS** rounds to the next power of 2




local peak finding


max in window



peak interpolation



peak interpolation



peak interpolation

great for **module A**!
no need to do this for
module B, Why?

m_{peak}

$$f_{\text{peak}} \approx f_2 + \frac{m_1 - m_3}{m_3 - 2m_2 + m_1} \frac{\Delta f}{2}$$

(f_2, m_2)

quadratic
approximation

(f_1, m_1)

good resource:

[https://
www.dsprelated.com/
freebooks/sasp/
Quadratic_Interpolatio
n_Spectral_Peaks.html](https://www.dsprelated.com/freebooks/sasp/Quadratic_Interpolation_Spectral_Peaks.html)

(f_3, m_3)


f_1

f_{peak}



f_2

f_3


the doppler effect



the doppler effect



the doppler effect



the doppler effect

The diagram shows the Doppler effect formula $\Delta f = \frac{V_{object}}{c} f_0$ with four callout boxes. A box labeled 'change in frequency' points to Δf . A box labeled 'velocity of object' points to V_{object} . A box labeled 'speed of sound' points to c . A box labeled 'frequency of source' points to f_0 .


$$\Delta f = \frac{V_{object}}{c} f_0$$

change in frequency

velocity of object

speed of sound

frequency of source




fts from

linear

db

db zoomed (freq axis)




Questions on the FFT/audio

- we are about to move to motion processing...
- so ask now!
- ...or later...

and now ...

- core motion
- A-series fusion SoC (previously M-series co-processor)



A-series fusion processor

- separate system on chip that reads all motion data from all “motion” sensors on the phone


- accelerometer
- magnetometer (compass)
- gyroscope
- barometer



- motion processor
- neural network engine
- GPU
- CPUs

- mediates all access to data



- battery life++
- parallel processing++
- overhead += 0, seriously



- sensor fusion for more accurate analysis, very cool

motion lecture agenda

- today: activity recognition through API
- today: pedometer step counting through API
- next time: raw motion data gathering



```
CMotion *deviceMotion;
CMotion.gravity;
CMotion.userAcceleration;
```

```
CMAcceleration gravity;
CMAcceleration userAcceleration;
```

```
gravity.x;
gravity.y;
gravity.z;

userAcceleration.x;
userAcceleration.y;
userAcceleration.z;
```

x=+9.81

acceleration

```
deviceMotion.rotationRate;
CMRotationRate rotationRate;
rotX[head] = rotationRate.x;
rotY[head] = rotationRate.y;
rotZ[head] = rotationRate.z;
```

```
deviceMotion.magneticField;
CMCalibratedMagneticField magneticField;
```

```
magneticField.field.x;
magneticField.field.y;
magneticField.field.z;
```

```
magneticField.accuracy;
```

magnetic field


```
deviceMotion.attitude;
CMAttitude* attitude;
```

```
attitude.roll;
attitude.pitch;
attitude.yaw;
```

device position

high level streams

- not just raw data!
 - the A-fusion series does sophisticated analysis of sensor data for you
 - enables naive access to “high level” information
- can register your app to receive “updates” from the co-processor unit
 - steps taken (and saved state of steps)
 - some common activity
 - running, walking, **cycling**, still, in car, unknown



activity from A-series

- uses the “core motion” framework (CM)
- mediated through the “CMActivityManager”
 - is device capable of activity?
 - query past activities (up to 7 days)
 - subscribe to changes
- interaction completely based on blocks and handlers

More help: <https://developer.apple.com/videos/wwdc/2014/>

Navigate to: **Motion Tracking and Core Motion Framework**

subscribe to activity



```
import CoreMotion
```

import framework

```
let activityManager = CMMotionActivityManager()
```

```
let customQueue = OperationQueue() // not the main
```

declare activity manager

```
override func viewDidLoad() {  
    super.viewDidLoad()
```

device capable?

```
    if CMMotionActivityManager.isActivityAvailable() {  
        self.activityManager.startActivityUpdatesToQueue(customQueue)  
        { (activity:CMMotionActivity?) -> Void in  
            NSLog("%@",activity!.description)  
        }  
    }  
}
```

closure to handle updates
(this one just prints description)

```
override func viewWillAppear(animated: Bool) {  
    if CMMotionActivityManager.isActivityAvailable() {  
        self.activityManager.stopActivityUpdates()  
    }  
    super.viewWillAppear(animated)  
}
```

end subscription

what's in an update?

- updated when any part of activity estimate changes
- each update is a CMMotionActivity class instance
 - startDate (down to seconds)
 - walking {0,1}
 - stationary {0,1}
 - running {0,1}
 - cycling {0, 1}
 - automotive {0,1}
 - unknown {0,1}
 - confidence {Low, Medium, High}



```
startActivityUpdatesToQueue:[NSOperationQueue mainQueue]
    withHandler:^(CMMotionActivity *activity)
{
    // do something with the activity info!
}];
```

```
self.activityManager.startActivityUpdatesToQueue(customQueue)
{ (activity:CMMotionActivity?) -> Void in
    // do something with the activity info!
}
```



example update

inside
handler



```
startActivityUpdatesToQueue:[NSOperationQueue mainQueue]
    withHandler:^(CMMotionActivity *activity) {
        // do something with the activity info!
    }];
```

from notification

```
// enum for confidence is 0=low,1=medium,2=high
NSLog(@" confidence:%ld \n stationary: %d \n walking: %d \n run: %d \n cycle %d \n in car: %d",
    activity.confidence,
    activity.stationary,
    activity.walking,
    activity.running,
    activity.cycling,
    activity.automotive);
```

access fields easily

```
switch (activity.confidence) {
    case CMMotionActivityConfidenceLow:
        self.confidenceLabel.text = @"low";
        break;
    case CMMotionActivityConfidenceMedium:
        self.confidenceLabel.text = @"med.";
        break;
    case CMMotionActivityConfidenceHigh:
        self.confidenceLabel.text = @"high";
        break;
    default:
        break;
}
```

look at confidence

what's in an update?

Example Scenarios

Device scenarios	stationary	walking	running	automotive	cycling	unknown
On table	true	false	false	false	false	false
On runner's upper arm	false	false	true	false	false	false
In dash of idling vehicle	true	false	false	true	false	false
In dash of moving vehicle	false	false	false	true	false	false
Passenger checking email	false	false	false	false	false	false
Immediately after reboot	false	false	false	false	false	true
In zumba class	false	false	false	false	false	false

<https://developer.apple.com/videos/wwdc/2014/>

what's in an update?

Motion Activity

Walking

Performance is fairly insensitive to location

- Detection can be suppressed when device is in hand

Relatively low latency

Very accurate, on average

- Expect intermittent transitions into and out of walking state



<https://developer.apple.com/videos/wwdc/2014/>

what's in an update?

Motion Activity

Running

Completely insensitive to location

Shortest latency

Most accurate classification



<https://developer.apple.com/videos/wwdc/2014/>

what's in an update?

Motion Activity


Automotive

Performance is sensitive to location

- Works best if device is mounted, or placed in dash or in cup holder

Variable latency

Relies on other information sources when available



<https://developer.apple.com/videos/wwdc/2014/>

what's in an update?

Motion Activity

Cycling

Performance is very sensitive to location

- Works best if device is worn on upper arm


Longest latency

- Best for retrospective use cases



<https://developer.apple.com/videos/wwdc/2014/>

Motion Processing Architecture



<https://developer.apple.com/videos/wwdc/2014/>

past activity

- query for an array of CMMotionActivity activities

```
// example of querying from certain dates
```

```
NSDate *now = [NSDate date];
```

```
NSDate *from = [NSDate dateWithTimeInterval:-60*60*24 sinceDate:now];
```

setup date range

set dates

```
[self.motionActivityManager queryActivityStartingFromDate:from  
    toDate:now  
    toQueue:[NSOperationQueue mainQueue]
```

set queue

```
withHandler:^(NSArray *activities, NSError *error) {
```

```
    for(CMMotionActivity *cmAct in activities)
```

```
    {
```

```
        NSLog(@"At %@, user was walking %d", cmAct.startDate, cmAct.walking);
```

```
    }
```

```
    }];
```

handle error!

handle output

- can you guess what the swift code looks like?

more than activity

- also tracks pedometer information during each activity
- like activity: setup as a **push** system (subscribe)
- pedometer: special handling from the A-series?
 - CMPedometer


Pedometer

Step counting

Consistent performance across body locations

Extremely accurate

Robust to extraneous motions



Pedometer


Stride estimation

Consistent performance across body locations

Consistent performance across pace

Extremely accurate

Adapts to the user over time



<https://developer.apple.com/videos/wwdc/2014/>

pedometer use



```
let pedometer = CMPedometer()

if CMPedometer.isStepCountingAvailable(){
    pedometer.startPedometerUpdatesFromDate(NSDate())
    { (pedData: CMPedometerData?, error: NSError?) -> Void in
        NSLog("%@", pedData.description)
    }
}

if CMPedometer.isStepCountingAvailable(){
    self.pedometer.stopPedometerUpdates()
}
```

declare and init

available on this device?

closure handler for updates

unsubscribe

pedometer use

revisiting

declare and init

available on this device?

```
let pedometer = CMPedometer()

if CMPedometer.isStepCountingAvailable(){
    pedometer.startPedometerUpdatesFromDate(NSDate())
    { (pedData: CMPedometerData?, error: NSError?) -> Void in
        NSLog("%@", pedData.description)
    }
}
```


properties from step counter

```
if CMPedometer.isStepCountingAvailable(){
    self.pedometer.stopPedometerUpdates()
}
```

unsubscribe

```
CMPedometerData,<startDate 2021-09-21
13:56:54 +0000 endDate 2021-09-21 13:57:17
+0000 steps 35 distance 27.57728308765218
floorsAscended 0 floorsDescended 0
currentPace 0.5944125511973894
currentCadence 2.17218804359436
averageActivePace 0.6163431784950018>
```

querying past steps



handle error!

```
let now = NSDate()
let from = now.dateByAddingTimeInterval(-60*60*24)


self.pedometer.queryPedometerDataFromDate(from, toDate: now)
{ (pedData: CMPedometerData?, error: NSError?) -> Void in

    let aggregated_string = "Steps: \(pedData.numberOfSteps) \n
                             Distance \(pedData.distance) \n
                             Floors: \(pedData.floorsAscended.integerValue)"

    dispatch_async(dispatch_get_main_queue()){
        self.activityLabel.text = aggregated_string
    }
}
```


access properties

pedometer/activity demo



if time!

MOBILE SENSING LEARNING



CS5323 & 7323

Mobile Sensing and Learning

doppler and activity monitoring



Eric C. Larson, Lyle School of Engineering,
Computer Science, Southern Methodist University

supplemental slides

- vector trajectory


resolution for the FFT

optional



256 points

next 256 points=512 total points




solution!

zero padding

noise in the FFT

optional

- variance around actual magnitude unavoidable



phone trajectory

- what direction is the phone (user) headed?

- direction could be:

- cardinal {N, S, E, W}

GPS and magnetometer

- altitude {sea level, +30 feet, etc.}

GPS

- relative altitude {up, down}

motion sensors

- relative trajectory {left, right, straight}

motion sensors

- how should we sense each of these?

up/down movement

- questions:
 - are we accelerating?
 - in what direction are we accelerating?
 - are we accelerating opposite of gravity?

which way is gravity?

`deviceMotion.gravity.{x,y,z}`

which way is the phone accelerating?


`deviceMotion.userAcceleration.{x,y,z}`

vectors



vector direction

- how much of one vector is in the direction of another?
- projections



$$\frac{A \cdot B}{|A|}$$
$$\frac{(5,5) \cdot (5,2)}{|(5,2)|}$$
$$\frac{5*5 + 5*2}{\sqrt{(5^2 + 2^2)}} = \frac{35}{\sqrt{29}} \sim 6.5$$

vector direction

- acceleration of the user towards or away from gravity?

```
CMAcceleration gravity, CMAcceleration userAccel
```

```
float dotProduct =  
    gravity.x*userAccel.x + gravity.y*userAccel.y + gravity.z*userAccel.z;
```

```
float normDotProd =  
    dotProduct / (gravity.x*gravity.x + gravity.y*gravity.y + gravity.z*gravity.z);
```

positive acceleration is speeding up
negative acceleration is slowing down

vector acceleration demo

- don't drop it!

profiling demo

- using the instruments panel in Xcode
 - memory leaks
 - general efficiency
 - excellent integration with iOS